

Step 1: Power Off the Phone

“First, turn off your iPhone completely.”

Step 2: Remove Bottom Screws

“Use the P2 screwdriver to remove the two screws at the bottom of the phone near the charging port.”

Step 3: Heat the Screen Edges

“Gently heat the edges of the phone with a heat gun or hair dryer for about 30–45 seconds. This softens the adhesive and makes opening the screen easier.”

Step 4: Lift the Screen

“Place a suction cup at the bottom of the screen and pull gently to create a gap. Insert your plastic spudger and slide it along the sides to loosen the screen. Open the phone from the right side, like a book. Be careful — the flex cables are short.”

Step 5: Disconnect the Battery

“Use your tri-point screwdriver to remove the shield covering the battery connector. Disconnect the battery first to prevent any electrical damage.”

Step 6: Disconnect Display & Face ID Flex Cables

“Remove the second shield over the display connectors. Then disconnect the screen cables and the front sensor flex.”

Step 7: Transfer Front Sensor Assembly (Face ID & Ear Speaker)

“This part is delicate — Face ID is tied to your original phone. Use your Y000 screwdriver to remove the earpiece and sensor assembly from the old screen. Gently lift it out using tweezers and install it into the new screen. Be careful not to damage the flex cable.”

Step 8: Reconnect and Reassemble

“Reconnect the display and sensor cables. Then reconnect the battery. Test-fit the screen to make sure everything aligns properly.”

Step 9: Close the Phone

“Once everything is in place, press the screen down gently starting from the top. Secure the two bottom screws using your pentalobe screwdriver.”

Step 10: Final Test

“Power on the phone and make sure everything is working:

- Touch response
- Display brightness and color
- Face ID
- Earpiece sound
- Front camera”