

Step 1: Power Off the Phone

“Start by powering off your iPhone completely.”

Step 2: Remove the Bottom Screws

“Use your P2 screwdriver to take out the two screws on both sides of the Lightning port.”

Step 3: Heat & Lift the Screen

“Use a heat gun or hair dryer to warm the edges for about 30–45 seconds. Place your suction cup near the bottom, lift slightly, and slide in your spudger to work your way around the screen.” “Open it from the right side, like a book — don’t lift too far, the Face ID cable is connected near the top.”

Step 4: Disconnect the Battery

“Use your Y000 screwdriver to remove the battery connector shield. Disconnect the battery to prevent shorting anything.”

Step 5: Disconnect Display Cables

“Remove the shield over the display connectors and unplug the display and digitizer cables.”

Step 6: Transfer Face ID & Earpiece Assembly

“Now, remove the ear speaker + front sensor module from the old screen. Be careful — the Face ID flex cable is fragile. Use the Y000 screwdriver to remove the screws, and gently lift the assembly with tweezers.” “Transfer the module to your new screen.”

Step 7: Reconnect Everything

“Reconnect the display cables, then the battery. Make sure all connections are secure.”

Step 8: Seal the Phone

“Carefully close the screen, aligning it from the top down. Press evenly and reinstall the two bottom screws.”

Step 9: Final Test

“Power on the phone and test:

- Touch responsiveness

- Brightness
- Face ID
- Camera & speaker”